

The purpose of this Quick Reference Guide is to familiarise the driver with the layout of the vehicle controls.

#### **Vehicle Security**

See Security System Handbook.

#### **Sound System**

See Sound System Handbook.

#### **Climate Control**

See Driver's Handbook, Section 5.

#### **Underbonnet Servicing**

See Vehicle Care Handbook, Section 3.

#### **Wheel Changing and Jacking**

See Vehicle Care Handbook, Section 4.

*JAGUAR XK8*

**QUICK GUIDE**






### ◀ Key-ring Transmitter

- Lock.
  - Un-lock.
  - Headlamp convenience.
  - Luggage compartment release.
- See Security System Handbook

### Ignition/Starter ▶ Switch

See page 56.




Page numbers refer to Driver's Handbook



### ◀ Steering Column Adjustment

See page 52.





### ▶ Door Switch Pack

- 1 Door mirror adjustment switch. See page 53.
- 2 Window operation switches. See page 34.

### Driving Position Memory Buttons

See page 51.




### ▶ Seat Adjustment Switches See page 49.

- 1 Seat cushion.
- 2 Seat back.
- 3 Lumbar support.

### ◀ Front Seat Belt Height Adjustment


See page 64.



### Front Seat ▶ Back Tilt

See page 50.





### ◀ Luggage Compartment Layout

- 1 Literature pack which includes the Vehicle Care Handbooks.
- 2 Spare wheel and wheel changing equipment. *See Vehicle Care Handbook page 30.*
- 3 Battery. *See Vehicle Care Handbook page 59.*

### Tyre Pressures

See inside the front cover of the Driver's Handbook, page 81 in the Vehicle Care Handbook and the tyre recommendation label in the centre console storage compartment.

Note your recommended tyre pressures in the boxes.

Normal

Front

Rear

Maximum comfort


Front

Rear



### ▲ Fuses

*See Vehicle Care Handbook page 40.*



### ◀ Fuel Filler


*See page 58.*

### Bulb Changing ▶

*See Vehicle Care Handbook page 62.*









## Instruments and Controls

- 1 Map light switch. *See page 40.*
- 2 Interior rear view mirror. *See page 54.*
- 3 Garage door opener switches. *See page 69.*

- 4 Driver's airbag and horns. *See page 62 and 43.*
- 5 Sound system controls. *See Sound System Handbook.*
- 6 Valet switch. *See page 48.*
- 7 Luggage compartment remote release switch. *See page 48.*
- 8 Fuel flap release switch. *See page 58.*
- 9 Exterior lighting, direction indicator and trip cycle switches. *See page 37, 37 and 25.*
- 10 Instrument pack and warning lights. *See page 14.*
- 11 Message centre display. *See page 17.*
- 12 Trip computer switches. *See page 26.*
- 13 Windscreen wipers and washers, headlamp power wash switches. *See page 42 and 43.*
- 14 Cruise control switches. *See page 31.*
- 15 Instruments and warning lights. *See page 15.*
- 16 Hazard warning switch. *See page 39.*
- 17 Front seat heater switch. *See page 50.*
- 18 Rear fog lamps switch. *See page 39.*
- 19 Sport mode switch. *See page 29.*
- 20 Cruise control master switch. *See page 31.*
- 21 Roof switch (convertible only). *See page 95.*
- 22 Radio cassette player. *See Sound System Handbook.*
- 23 Front fog lamps switch. *See page 39.*
- 24 Automatic stability or traction control switch. *See page 33.*
- 25 Heated front screen switch. *See page 84.*
- 26 Heated rear screen switch. *See page 84.*



Page numbers refer to Driver's Handbook.

For more in-depth information the driver should study the Driver's Handbook, with particular reference to all **WARNINGS** and **Cautions**.